

1. Introduction

Thank you for purchasing PLANET 400 Watts 100~240V AC Redundant Power Supply Unit for XGS3-42000R:

XGS3-PWR-AC: 400 Watts AC power supply unit for XGS3-42000R

2. Physical Description

Front panel




Figure 1. Power slots of XGS3-42000R

Rear panel




Figure 2. Power sockets of XGS3-42000R

- 1 -

3. Install and remove the redundant power supply unit

Before installation, please be sure to read this user's manual carefully to complete machine installation. This manual shows how to quick install and remove the XGS3-PWR-AC from XGS3-42000R.

The XGS3-42000R equip with one 100~240V AC power supply unit in its standard package, the XGS3-42000R and also provide one spare power supply unit slot for option redundant power supply unit for XGS3-PWR-AC installation. The XGS3-PWR-AC shall enhance the reliability of XGS3-42000R.



The XGS3-42000R supports hot-swapping and power redundancy backup. This secondary AC power module can direct slid in to the Chassis while the System is operating.




Figure 3. Front panel of XGS3-42000R

To install the XGS3-PWR-AC into XGS3-42000R, please fasten the hand screw clockwise after slide in the XGS3-PWR-AC to the XGS3-42000R.



Plaes slid in the XGS3-PWR-AC module before plug-in the rear power cord.

- 3 -

- 4 -

www.planet.com.tw

400W
XGS3-PWR-AC

AC Power Supply

Effective Non-stop Power Backup Solution



User's Manual



PLANET Technology Corp.
2351-A96090-000



To remove the XGS3-PWR-AC from XGS3-42000R, please loose the hand screws counter clockwise and pull out the XGS3-PWR-AC from the XGS3-42000R.



Note

Please put back the front cover after the XGS3-PWR-AC module is removed.



Caution

Please plug-out the power cord before plug-out the XGS3-PWR-AC.




Figure 4. Install / remove the XGS3-PWR-AC